

Spark H₂O: Trace Level Moisture Analyzer At last, measurements made easy!

GASES & CHEMICALS CEMS	ENERGY	ATMOSPHERIC	SEMI & HB LED	SYNGAS	LABORATORY
------------------------	--------	-------------	---------------	--------	------------

For the first time, powerful advanced spectroscopy is available at a popular price for a host of applications, from quality assurance to cylinder filling, as well as welding, medical, industrial and high-purity gas production; bulk delivery and distribution transfer points; and more. Say goodbye to cumbersome, complex, costly and labor-intensive 20th century technology. Gone is the need for calibration, spare parts, limited measurement ranges, and worries about drift and downtime. Plus, it's a joy to start up and to operate.

The compact and affordable Spark H₂O offers:

- Powerful, proven Cavity Ring-Down Spectroscopy (CRDS) technology
- Self-tuning and auto-calibration
- Extremely low Cost of Ownership

- Ethernet, 4-20 mA and RS-232 connectivity
 - Fast response with low gas consumption
- H₂O analysis over a vast range: 15 ppb to 2000 ppm!

The original maker of CRDS analyzers, Tiger Optics has been serving users worldwide for over a dozen years. We are in HyCO plants, with our Class I, Div 2 rated CO-rekt analyzer; in nuclear plants, where we are Safety Integrity Level One (SIL 1) approved; and we are widely used in semiconductor fabs for bulk and specialty monitoring, in addition to toolmounted process control and QA/QC of purifiers and gas delivery systems. We are the designated standard under SEMI F-112-0613 for determining moisture dry-down characteristics of such systems. Tiger Optics was used by NIST to name the new hydrogen chloride protocol for continuous emissions monitoring, and we now measure HCl in stack gas at coal-fired utilities.

Put a little Spark in your life!





See Page 3 for our **NEW** optional add-on packages!

Spark H₂O Trace Level Moisture Analyzer



Performance		
Operating range	See table below	
Detection limit (LDL,	See table below	
24 h peak-to-peak variation)		
Sensitivity (3o)	See table below	
Precision (1 σ , greater of)	± 0.75% or 1/3 of Sensitivity	
Accuracy (greater of)	± 4% or the LDL	
Speed of response	< 3 minutes to 90%	
Environmental conditions	10°C – 40°C	
	30% – 80% RH (non-condensing)	
Storage temperature	-10°C – 50°C	

Gas Handling System and Conditions

Wetted materials	316L stainless steel	
	10 Ra surface finish	
Gas connections	1/4" male VCR inlet and outlet	
Inlet pressure*	10 – 125 psig (1.7 – 9.6 bara)	
Flow rate	~1.4 slpm	
Sample gases	Most inert, toxic, and	
	passive matrices	
Gas temperature	Up to 60°C	

	× •*
Dimensions	H x W x D [in (mm)]
Standard sensor	8.75 x 8.5 x 23.6 (222 x 216 x 599)
Sensor rack	8.75 x 19 x 23.6 (222 x 483 x 599)
(fits up to two sensors)	
Weight	
Standard sensor	32 lbs (14.5 kg)
Electrical	
Alarm indicators	2 user programmable
	1 system fault
	Form C relays
Power requirements	90 – 240 VAC, 50/60 Hz
Power consumption	40 Watts max.
Signal output	Isolated 4–20 mA per sensor
User interfaces	5.7" LCD touchscreen
	10/100 Base-T Ethernet
	802.11g Wireless (optional)
	RS-232

Performance, H ₂ O:	Range	LDL	Sensitivity
In Nitrogen	0 – 2000 ppm	15 ppb	12 ppb
In Oxygen	0 – 1000 ppm	7 ppb	6 ppb
In Argon	0 – 900 ppm	6 ppb	4.5 ppb
In Helium	0 – 450 ppm	4 ppb	3 ppb
In Hydrogen	0 – 1750 ppm	10 ppb	7.5 ppb
In Clean Dry Air (CDA)	0 – 1800 ppm	14 ppb	10 ppb
In Neon	0 – 450 ppm	40 ppb	30 ppb
In Krypton	0 – 1100 ppm	7 ppb	5.5 ppb
In Xenon	0 – 1300 ppm	10 ppb	7.5 ppb

* Inlet pressure as low as 0 psig available with Atmospheric Pressure Sampling option Contact us for additional analytes and matrices • U.S. Patent # 7,277,177





Spark H₂O Trace Level Moisture Analyzer

Optional Packages

Customize your Spark H₂O analyzer with these powerful add-ons:

Atmospheric Pressure Sampling

- Sample in Nitrogen and Clean Dry Air (CDA) with lower inlet pressure, down to 0 psig (may require vacuum pump)
- Wider inlet pressure range for H₂O measurement in Air Separation Units (ASUs)
- Expanded use with moisture standards and Low-Frost Point Generators (LFPGs)



Dew Point Measurement

- Moisture measurement can be displayed as Dew Point (in units of °C, °F or K) or Concentration (as volume or weight basis)
- Ideal for use as transfer standard for Dew Point-based moisture generators no unit conversion necessary
- Wide Dew Point measurement range from -100°C to -13°C



у

h

sct bisplay Unit Concentration (PPBv) Concentration (PPBw) Dew Point (Degrees Calsius) Dew Point (Kalvin) Dew Point (Kalvin)

Linear Fit Mode

- Linear y = a x + b fit function permits user-defined calibration curves with programmable slope (a) and offset (b)
- Automatically adjusts readings to factor in dilution probes and sampling system offsets, while retaining the absolute data
- Enables calibration against external standards, when mandated by rules or regulations



- Low-cost and easy remote certification process, with no need to return the analyzer to the factory
- Annual re-certification by Tiger Optics ensures that your analyzer continues to meet its original specifications
- Up-to-date Verification Certificate to comply with your QA/QC standards



Tiger Optics, LLC 250 Titus Avenue, Warrington, PA 18976 Phone: +1 (215) 343 6600 • Fax: +1 (215) 343 4194 sales@tigeroptics.com • www.tigeroptics.com

Tige tics

